


# Atlantis Matrix™ / D-Raintank™ Typical Tank Inlet Outlet Design


## Inlet Pipe

Non-corrosive hose clamp or tape used to fasten liner to pipes to prevent backfill from entering structure.




Non-woven  
Polypropylene  
Geotextile filter  
fabric encasing  
Atlantis Matrix™ /  
D-Raintank™

## Outlet Pipe



Non-woven  
Polypropylene  
Geotextile filter  
fabric encasing  
Atlantis Matrix™ /  
D-Raintank™

Non-corrosive hose clamp or  
tape used to fasten liner to  
pipes to prevent backfill from  
entering structure.



## End View of Pipe

1. Cut an 'X' in the Geotextile slightly smaller than the pipe.
2. Insert the pipe.
3. Pull the Geotextile up and around the pipe creating a 'boot'.
4. Secure with hose clamp or tape.

**DISCLAIMER:** All information provided in this publication is correct to the best of the Company's knowledge and is given out in good faith. This information is intended only as a general guide, no responsibility can be accepted for any errors, omissions or In-correct assumption. As each project is unique, and as Rehirth Pty Ltd, Atlantis Water Management, Atlantis Corporation Pty Ltd and Its Distributors and Agents World Wide have no direct control over the methods employed by the User in Specifying, Installing or Supervising of its products hence no Responsibility is accepted by Rehirth Pty Ltd, Atlantis Water Management, Atlantis Corporation Pty Ltd and Its Distributors and Agents World Wide. Users should satisfy themselves as to the suitability of the product for their purpose.

All product designs, and specification are subject to change without further notice. All Atlantis products are tested in approved NATA laboratories, and safe allowed tolerance should be practised in actual field, due to any unforeseen situations, onsite and on products. All material contained within this brochure is Copy write, and belongs to Rehirth Pty Ltd Australia. No part of this brochure may be reproduced or transmitted in any form or by any means electronic, mechanical, photocopying, recording or otherwise, without prior written permission of Rehirth Pty Ltd, Australia, Atlantis Water Management, Atlantis Corporation Pty Ltd. Copyright © 2002 by Rehirth Pty Ltd, Australia, Atlantis Water Management, Atlantis Corporation Pty Ltd, Australia.